

## ❖ Overview


### GPS Navigation Features

- ❖ Electronic maps with roads, freeways, highways, railways, rivers, lakes, points of interest, etc.
- ❖ GPS positioning
- ❖ Optimal route calculation and trip plan
- ❖ Friendly and efficient navigation with turn-by-turn, voice, and visual guidance
- ❖ Various ways for searching a location on the map
  - Using a known address
  - Using a POI (point of interest)
  - Using Favorites (personal stored locations)
  - Using History (previous destinations)
- ❖ Recording and playback of journeys
- ❖ Viewing modes for different needs and situations:
  - 2D or 3D
  - Daytime or nighttime view
  - Turn-by-turn view of the route
  - Driving direction of the route

### Other Features

- ❖ MP3 Player: playing MP3 music.
- ❖ Photo Viewer
- ❖ Movie Player: playing movies in wmv, asf, avi format
- ❖ Calculator

### Front Components




Ref	Component	Description
❶	<b>Charge Indicator</b>	<ul style="list-style-type: none"><li>◆ Battery Full -- Green (Static)</li><li>◆ Battery in charging -- Green (twinkle)</li></ul>
❷	<b>GPS signal indicator</b>	<ul style="list-style-type: none"><li>◆GPS Signal in allocating – Red (twinkle)</li><li>◆GPS Signal allocation finished – Green (static)</li></ul>
❸	<b>Bluetooth indicator</b>	◆Disable. ( Bluetooth only support Model No.NAV-6220 )

## . System Settings

Your device is supplied with default settings. You may also customize the settings to suit your personal needs. Once you change settings, your new settings will remain until either you change them again, or until battery cutoff switch is turned off and then back on again, which resets the unit to factory defaults.

### 3.1 Using System Settings

Tap the Setup button on the Main screen.



The Setup screen contains six buttons as shown below. The following sections describe these six buttons and their functions.

